

# Mipa 1K-Primer N 75 Spray

Item no. 21310 + Colour number

Technical data sheet

page 1 / 3

## Intended use

Mipa 1K-Primer N 75 Spray is an outstanding one-component primer with excellent adhesion, very high filling power and a fast sandability. Mipa 1K-Primer N 75 adheres to iron, steel as well as to recoatable plastics commonly used in the automotive sector like POM, PU, ABS, PVC, PC, PS, PA, PP/EPDM (if necessary, we recommend a recoating test).

## Processing instructions



### Substrates

iron, steel and plastics commonly used in the automotive sector like POM, PU, ABS, PVC, PC, PS, PA, PP/EPDM

### Pre-treatment / cleansing

Pre-clean with Mipa Silikonentferner.

Please refer to the section "Substrate preparation" for detailed information.

### Characteristics

Fast drying  
Excellent sandability  
Very high filling power  
Outstanding adhesion  
Recoatable with all common solvent and water based 1K- and 2K-topcoat systems

## Colour / gloss level

white (0001) / grey (0002) / black (0003)




### Preparation

Before use, shake can vigorously for 1 - 2 minutes!



### Application

Spray to test - spray distance approx. 20 - 30 cm  
2 - 3 coats, dry film thickness: 70 - 80 µm




### Flash-off time

3 - 5 min between coats



### After use

After use, turn can upside down and spray until the valve is clean, this prevents the valve from clogging up.



## Drying times at 20 °C

|                            |  |
|----------------------------|--|
| Dust dry after approx.     | 5 - 10 min   |
| Set to touch after approx. | 10 - 15 min  |
| Overcoatable after approx. | 20 - 30 min  |
| Sandable after approx.     | 30 min, alternatively after 15 min drying at 60 °C |



## Subsequent processing

Dry sanding: For 1-layer topcoats P 400  
For 2-layer topcoats P 500 - 600



Wet sanding: For 1-layer topcoats P 600  
For 2-layer topcoats P 800 - 1000

**Processing conditions** From +10 °C and up to 80 % relative humidity. Ensure adequate air ventilation.

**Storage** Can be stored for 2 years in cool and dry places.

**VOC-regulation** EU limit value for the product (cat. B/e): 840 g/l  
This product contains max. 700 g/l of VOC.

**Safety information** See safety data sheet

## Processing instructions

Do not overcoat with polyester-based materials.

### Substrate preparation:

The substrate must be clean and dry. Remove oil, grease, rust, mill skill, rolling skin as well as other substances impairing the function of the coating!

Remove old coatings or primers that have not cured or are not sound.

Do not use on thermoplastic substrates.

### Steel substrates:

1. Pre-clean with Mipa Silikonentferner.
2. Then dry sand with P 120.
3. Afterwards, degrease with Mipa Silikonentferner.

### GRP:

1. Before painting, reheat the object to be painted for 60 minutes at 60°C.
2. Degrease with Mipa Kunststoffreiniger antistatisch or Mipa Silikonentferner.
3. Sand thoroughly with P 240 - P 320.
4. Clean again with Mipa Kunststoffreiniger antistatisch or Mipa Silikonentferner.
5. Allow parts to dry completely.
6. Recommended for neutralising electrostatic charges:

Blow off the surfaces by means of MP Ionisierungspistole X-ION, cleans and neutralises in one operation, reduces dust inclusions when coating. In addition, this avoids differences in pigment orientation when overcoating with metallic/ effect basecoats.

ATTENTION: Releasing agents must be removed completely! After the previously mentioned preparation, we recommend doing a wetting test with water. If the water drops roll off quickly, repeat the pre-treatment.

**Intact, sound old paintworks, factory paintings:**

1. Pre-clean with Mipa Silikonentferner.
2. Then sand with P 320.
3. Afterwards, degrease with Mipa Silikonentferner.

**Cathodic e-coating / shop primer:**

1. Pre-clean with Mipa Silikonentferner.
2. Then sand with MP Softpad Superfine or with P 320.
3. Afterwards, degrease with Mipa Silikonentferner.

**Plastic substrates:**

1. Before painting, reheat the object to be painted for 60 minutes at 60°C.
2. Degrease with Mipa Kunststoffreiniger antistatisch or Mipa Silikonentferner.
3. Sand thoroughly with MP Softpad Superfine using Mipa Kunststoffreiniger antistatisch or Mipa Silikonentferner.
4. Clean again with Mipa Kunststoffreiniger antistatisch or Mipa Silikonentferner.
5. Allow parts to dry completely.
6. Recommended for neutralising electrostatic charges:

Blow off the surfaces by means of MP Ionisierungspistole X-ION, cleans and neutralises in one operation, reduces dust inclusions when coating. In addition, this avoids differences in pigment orientation when overcoating with metallic/ effect basecoats.

ATTENTION: Releasing agents must be removed completely!

After the previously mentioned preparation, we recommend doing a wetting test with water. If the water drops roll off quickly, repeat the pre-treatment. Due to the wide range of plastic types and compounds available on the market, preliminary tests on original parts are indispensable.

**When used as sanding filler, follow the sanding instructions below after drying:**

1. For 1-layer topcoats, sand dry with P 400 or wet with P 600.
2. For 2-layer topcoats, we recommend dry sanding with P 500 / 600 or wet sanding with P 800 / 1000.
3. Thoroughly remove sanding dust using Mipa Silikonentferner or Mipa WBS Reiniger or Mipa WBS Reiniger FINAL. Use clean, lint-free wiping cloths.

It is recommended that the sanded surfaces and/ or joints, grooves etc. are thoroughly blown off with oil-free compressed air.

4. Then clean the surface to be painted with Mipa Silikonentferner, Mipa WBS Reiniger or Mipa WBS Reiniger FINAL using a new, clean cloth.

Once the cleaners have dried completely without leaving streaks, apply the topcoat.