

Mipa Felgensilber Spray

Item no 21501 0060

Technical data sheet

page 1 / 2

Intended use

Mipa Felgensilber Spray is a fast drying, robust wheel rim paint based on a highly pigmented acrylic quality. Ensures excellent adhesion and resistance to mechanical stress and chemical agents. Especially suitable to restore and to renew wheel rims, wheel trims, vehicle parts, etc.

Processing instructions



Substrates

Primed steel and aluminium rims, cured and sanded old paintworks.

Pre-treatment / cleansing

Please refer to the section "Substrate preparation" for detailed information.

Characteristics

Fast drying
Weather-resistant, protects against environmental influences
Scratch- and shock-resistant

Colour / gloss level

Aluminium silver




Preparation

Before use, shake can vigorously for 1 - 2 minutes!



Application

Spray to test - spray distance approx. 20 - 30 cm
2 - 3 coats, dry film thickness: 40 - 50 µm




Flash-off time

3 - 5 min between coats



After use

After use, turn can upside down and spray until the valve is clean, this prevents the valve from clogging up.



Drying time at 20 °C

Dust dry after approx.	5 - 10 min
Set to touch after approx.	20 - 30 min
Ready for assembly after approx.	12 h

Processing conditions From +10 °C and up to 80 % relative humidity. Ensure adequate air ventilation.

Storage Can be stored for 2 years in cool and dry places.

VOC-regulation EU limit value for the product (cat. B/e): 840 g/l
This product contains max. 800 g/l of VOC.

Safety information See safety data sheet

Substrate preparation:

The substrate must be clean and dry. Remove oil, grease, rust, mill skill, rolling skin as well as other substances impairing the function of the coating!

Remove old coatings or primers that have not cured or are not sound.

Do not use on thermoplastic substrates

Steel substrates:

1. Pre-clean with Mipa Silikonentferner.
2. Then dry sand with P 120.
3. Afterwards, degrease with Mipa Silikonentferner.

Aluminium substrates:

1. Pre-clean with Mipa Silikonentferner.
2. Then dry sand with P 220.
3. Afterwards, degrease with Mipa Silikonentferner.

For application on steel and aluminium: First prime with suitable Mipa adhesion promoters or primers / fillers, e.g. Mipa Fast-Filler-Spray, Mipa 1K-Epoxy-Primer-Spray, Mipa Rapidprimer-Spray, Mipa Rapidfiller-Spray, Mipa Etch-Filler HB Spray, Mipa 2K-EP-Grundierfiller-Spray. The corresponding Mipa technical data sheets must be observed.

Intact, sound old paintworks, factory paintings:

1. Pre-clean with Mipa Silikonentferner.
2. Then sand with P 400 - 500.
3. Afterwards, degrease with Mipa Silikonentferner.

Cathodic e-coating / shop primer:

1. Pre-clean with Mipa Silikonentferner.
2. Then sand with MP Softpad Superfine or with P 400 - 500.
3. Afterwards, degrease with Mipa Silikonentferner.