Mipa Heizkörper-Spray

Item no 68212 0000
Technical data sheet

page 1/2



Intended use

Mipa Heizkörper-Spray is a fast drying special varnish for radiators with warm water and steam central heating systems. Overhead spraying is possible without any problems.

Processing instructions



Substrates

Cured and sanded old paintworks, well dried Mipa 1K and 2K fillers.

Pre-treatment / cleansing

Pre-clean with Mipa Silikonentferner.

Please refer to the section "Substrate preparation" for detailed information.

Characteristics

Fast drying Scratch- and shock-resistant Resistant to temperatures up to 120 °C Resistant to yellowing up to 100 °C High surface hardness High gloss Overhead spraying without any problems

Colour / gloss level

RAL 9010, RAL 9016 / glossy RAL 7016 / satin matt



Preparation

Before use, shake can vigorously for 1 - 2 min!



Application

Spray to test - spray distance approx. 20 - 30 cm 2 - 3 coats, dry film thickness: 30 - 40 µm



Flash-off time

3 - 5 min between coats



After use

After use, turn can upside down and spray until the valve is clean, this prevents the valve from clogging up.

Version: en 0322

Mipa Heizkörper-Spray

Item no 68212 0000 **Technical data sheet**

page 2/2





Drying time at 20 °C

Dust dry after approx. 10 min

Set to touch after approx. 1 - 2 h

Ready for assembly after approx. 24 h

Processing conditions

From +10 °C and up to 80 % relative humidity. Ensure adequate air

ventilation.

Storage Can be stored for 2 years in cool and dry places.

VOC-regulationEU limit value for the product (cat. B/e): 840 g/l This product contains max. 660 g/l of VOC.

Safety information See safety data sheet

Processing instructions

With regard to colour shade RAL 7016 satin matt, please note that its gloss level is only stable up to 60 °C and that it may increase at higher temperatures.

Substrate preparation:

The substrate must be clean and dry. Remove oil, grease, rust as well as other substances impairing the function of the coating!

Remove old coatings or primers that have not cured or are not sound.

Do not use on thermoplastic substrates.

Steel substrates:

- 1. Pre-clean with Mipa Silikonentferner.
- 2. Then dry sand with P 120.
- 3. Afterwards, degrease with Mipa Silikonentferner.

For application on steel: First prime with suitable Mipa adhesion promoters or primers / fillers, e.g. Mipa Fast-Filler-Spray, Mipa 1K-Epoxy-Primer-Spray, Mipa Rapidprimer-Spray, Mipa Rapidfiller-Spray, Mipa Etch-Filler HB Spray, Mipa 2K-EP-Grundierfiller-Spray. The corresponding Mipa technical data sheets must be observed.

Intact, sound old paintworks, factory paintings:

- 1. Pre-clean with Mipa Silikonentferner.
- 2. Then sand with P 400 500.
- 3. Afterwards, degrease with Mipa Silikonentferner.

Version: en 0322